

マーシット1キロ粒剤 GS-1、GS-1W散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。
(調節目盛:グループC大)

GS-1	植付株数/坪				
	40	50	60	70	80
4条植	7.5	7.0	6.5	6.0	5.5
5条植	8.0	7.5	7.0	6.5	6.0
6条植	8.5	8.0	7.5	7.0	6.5

GS-1W	植付株数/坪				
	40	50	60	70	80
7条植	8.0	7.0	6.5	6.0	5.5
8条植	8.5	7.5	7.0	6.5	6.0
10条植	9.5	8.5	8.0	7.5	7.0

マーシエット1キロ粒剤 こまきちゃんCS-10(クボタ)散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	20	26
	株間	株/坪	目盛り	目盛り	目盛り
4 条 植	30	37	3.2	4.1	5.5
	24	46	2.5	3.2	4.3
	21	50	2.1	2.8	3.7
	18	60	1.8	2.3	3.1
	16	70	1.5	2.0	2.7
	14	80	1.3	1.7	2.3
	13	85	1.2	1.6	2.2
	12	90	1.1	1.4	2.0
5 条 植	30	37	4.1	5.2	6.9
	24	46	3.2	4.1	5.5
	21	50	2.8	3.6	4.7
	18	60	2.3	3.0	4.0
	16	70	2.0	2.6	3.5
	14	80	1.7	2.2	3.0
	13	85	1.6	2.1	2.8
	12	90	1.4	1.9	2.5
6 条 植	30	37	5.0	6.4	8.4
	24	46	3.9	5.0	6.6
	21	50	3.4	4.3	5.8
	18	60	2.9	3.7	4.9
	16	70	2.5	3.2	4.3
	14	80	2.1	2.8	3.7
	13	85	2.0	2.5	3.4
	12	90	1.8	2.3	3.1
8 条 植	30	37	6.8	8.6	11.3
	24	46	5.4	6.8	9.0
	21	50	4.7	5.9	7.8
	18	60	3.9	5.0	6.6
	16	70	3.5	4.4	5.9
	14	80	3.0	3.8	5.1
	13	85	2.7	3.5	4.7
	12	90	2.5	3.2	4.3
10 条 植	24	46	7.9	10.0	
	21	50	6.9	8.7	11.4
	18	60	5.9	7.4	9.8
	16	70	5.2	6.5	8.6
	14	80	4.5	5.7	7.5
	13	85			
	12	90	3.8	4.8	6.4

*この目安表は計算値です。実際の田植機には設定のない欄があります。

マーシット1キロ粒剤 こまきちゃんCS-20散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	20	26	PTO
	株間	株/坪	目盛り	目盛り	目盛り	目盛り
4 条 植	30	37	2.6	3.3	4.3	3.0
	24	46	2.1	2.6	3.4	2.4
	21	50	1.8	2.3	3.0	2.1
	18	60	1.6	2.0	2.6	1.8
	16	70	1.4	1.7	2.3	1.6
	14	80	1.2	1.5	2.0	1.4
	13	85	1.1	1.4	1.8	1.3
	12	90	1.0	1.3	1.7	1.2
5 条 植	30	37	3.3	4.1	5.4	3.7
	24	46	2.6	3.3	4.3	3.0
	21	50	2.3	2.9	3.8	2.6
	18	60	2.0	2.5	3.2	2.2
	16	70	1.7	2.2	2.9	2.0
	14	80	1.5	1.9	2.5	1.7
	13	85	1.4	1.8	2.3	1.6
	12	90	1.3	1.6	2.1	1.5
6 条 植	30	37	4.0	5.0	6.4	4.5
	24	46	3.2	4.0	5.2	3.6
	21	50	2.8	3.5	4.5	3.1
	18	60	2.4	3.0	3.9	2.7
	16	70	2.1	2.6	3.4	2.4
	14	80	1.8	2.3	3.0	2.1
	13	85	1.7	2.1	2.8	1.9
	12	90	1.6	2.0	2.6	1.8
8 条 植	30	37	5.3	6.6	8.6	
	24	46	4.2	5.3	6.9	
	21	50	3.7	4.6	6.0	
	18	60	3.2	4.0	5.2	
	16	70	2.8	3.5	4.6	
	14	80	2.5	3.1	4.0	
	13	85	2.3	2.9	3.7	
	12	90	2.1	2.6	3.4	
10 条 植	30	37	7.4			
	24	46	5.9			
	21	50	5.2			
	18	60	4.5			
	16	70	4.0			
	14	80	3.5			
	13	85	3.2			
	12	90	3.0			

*この目安表は計算値です。実際の田植機には設定のない欄があります。

マーシット 1キロ粒剤 こまきちゃんCS-30散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	20	26	PTO
	株間	株/坪	目盛り	目盛り	目盛り	目盛り
4 条 植	30	37	3.2	4.1	5.5	3.1
	24	46	2.5	3.2	4.3	2.5
	21	50	1.9	2.8	3.7	2.1
	18	60	1.6	2.3	3.1	1.8
	16	70	1.4	2.0	2.7	1.6
	14	80	1.2	1.7	2.3	1.4
	13	85	1.1	1.6	2.2	1.3
	12	90	1.0	1.4	2.0	1.2
5 条 植	30	37	4.1	5.2	6.9	3.9
	24	46	3.2	4.1	5.5	3.1
	21	50	2.8	3.6	4.7	2.7
	18	60	2.3	3.0	4.0	2.3
	16	70	2.0	2.6	3.5	2.0
	14	80	1.8	2.2	3.0	1.8
	13	85	1.6	2.1	2.8	1.6
	12	90	1.4	1.9	2.5	1.5
6 条 植	30	37	5.0	6.4	8.4	4.7
	24	46	3.9	5.0	6.6	3.7
	21	50	3.4	4.3	5.8	3.3
	18	60	2.9	3.7	4.9	2.8
	16	70	2.5	3.2	4.3	2.5
	14	80	2.1	2.8	3.7	2.1
	13	85	2.0	2.5	3.4	2.0
	12	90	1.8	2.3	3.1	1.8
8 条 植	30	37	6.8	8.6	11.3	
	24	46	5.4	6.8	9.0	
	21	50	4.7	5.9	7.8	
	18	60	3.9	5.0	6.6	
	16	70	3.5	4.4	5.9	
	14	80	3.0	3.8	5.1	
	13	85	2.7	3.5	4.7	
	12	90	2.5	3.2	4.3	
10 条 植	30	37	7.9			
	24	46	6.3			
	21	50	5.5			
	18	60	4.7			
	16	70	4.2			
	14	80	3.6			
	13	85	3.4			
	12	90	3.1			

*この目安表は計算値です。実際の田植機には設定のない欄があります。

マーシット 1キロ粒剤 CS-100散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

		5条	6条	8条
株間	株/坪	目盛り	目盛り	目盛り
30	37	3.9	4.7	6.3
24	46	3.1	3.7	5.0
21	50	2.7	3.3	4.4
18	60	2.3	2.8	3.7
16	70	2.0	2.5	3.3
14	80	1.8	2.1	2.9

マーシット1キロ粒剤 こまきちゃんSCS-10(井関)散布目安表

条間:30cm

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	18	20	24	28
	株間	株/坪	目盛り	目盛り	目盛り	目盛り	目盛り
4 条 植	30	37			3.0	3.7	
	26	42			2.5	3.1	
	23	48			2.2	2.7	
	22	50			2.1	2.6	
	18	61			1.6	2.0	
	16	69			1.4	1.8	
	14	79			1.2	1.5	
5 条 植	30	37	3.0	3.4	3.8	4.7	5.5
	26	42	2.5	2.9	3.3	4.0	4.7
	23	48	2.2	2.5	2.9	3.5	4.2
	22	50	2.1	2.4	2.7	3.3	4.0
	18	61	1.6	1.9	2.2	2.7	3.2
	16	69	1.4	1.6	1.9	2.3	2.8
	14	79	1.2	1.4	1.6	2.0	2.4
6 条 植	30	37	3.7	4.2	4.7	5.7	6.7
	26	42	3.1	3.6	4.0	4.9	5.8
	23	48	2.7	3.1	3.5	4.3	5.1
	22	50	2.6	3.0	3.3	4.1	4.8
	18	61	2.0	2.4	2.7	3.3	3.9
	16	69	1.8	2.0	2.3	2.9	3.4
	14	79	1.5	1.7	2.0	2.5	2.9
7 条 植	30	37	4.3	4.9	5.5	6.7	7.9
	26	42	3.7	4.2	4.7	5.8	6.8
	23	48	3.2	3.7	4.2	5.1	6.0
	22	50	3.1	3.5	4.0	4.8	5.7
	18	61	2.5	2.8	3.2	3.9	4.6
	16	69	2.1	2.5	2.8	3.4	4.0
	14	79	1.8	2.1	2.4	2.9	3.5
8 条 植	30	37	5.0	5.7	6.4	7.7	9.1
	26	42	4.3	4.9	5.5	6.6	7.8
	23	48	3.8	4.3	4.8	5.8	6.9
	22	50	3.6	4.1	4.6	5.6	6.6
	18	61	2.9	3.3	3.7	4.5	5.3
	16	69	2.5	2.9	3.2	3.9	4.7
	14	79	2.1	2.5	2.8	3.4	4.0

*この目安表は計算値です。実際の田植機には設定のない欄があります。

マーシット1キロ粒剤 こまきちゃんSCS-30(井関)散布目安表

条間:30cm

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	18	20	24	28
	株間	株/坪	目盛り	目盛り	目盛り	目盛り	目盛り
4 条 植	30	37			2.6	3.1	
	26	42			2.2	2.7	
	23	48			1.9	2.4	
	22	50			1.9	2.2	
	18	61			1.5	1.8	
	16	69			1.3	1.6	
	14	79			1.2	1.4	
5 条 植	30	37	2.6	2.9	3.2	3.9	4.6
	26	42	2.2	2.5	2.8	3.4	3.9
	23	48	1.9	2.2	2.5	3.0	3.5
	22	50	1.8	2.1	2.3	2.8	3.3
	18	61	1.5	1.7	1.9	2.3	2.7
	16	69	1.3	1.5	1.7	2.0	2.4
	14	79	1.2	1.3	1.5	1.8	2.1
6 条 植	30	37	3.1	3.5	3.9	4.7	5.5
	26	42	2.7	3.0	3.4	4.1	4.7
	23	48	2.4	2.7	3.0	3.6	4.2
	22	50	2.2	2.5	2.8	3.4	4.0
	18	61	1.8	2.1	2.3	2.8	3.3
	16	69	1.6	1.8	2.0	2.5	2.9
	14	79	1.4	1.6	1.8	2.1	2.5
7 条 植	30	37	3.6	4.1	4.6	5.5	6.4
	26	42	3.1	3.5	3.9	4.7	5.5
	23	48	2.8	3.1	3.5	4.2	4.9
	22	50	2.6	3.0	3.3	4.0	4.7
	18	61	2.1	2.4	2.7	3.3	3.8
	16	69	1.9	2.1	2.4	2.9	3.4
	14	79	1.6	1.9	2.1	2.5	2.9
8 条 植	30	37	4.2	4.7	5.2	6.3	7.3
	26	42	3.6	4.1	4.5	5.4	6.3
	23	48	3.2	3.6	4.0	4.8	5.6
	22	50	3.0	3.4	3.8	4.6	5.4
	18	61	2.5	2.8	3.1	3.7	4.4
	16	69	2.2	2.5	2.7	3.3	3.9
	14	79	1.9	2.1	2.4	2.9	3.4

*この目安表は計算値です。実際の田植機には設定のない欄があります。

マーシット 1キロ粒剤 SCS-100散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

	5条	6条	7条	8条
株間	目盛り	目盛り	目盛り	目盛り
Free	3.4	4.3	4.8	5.4

マーシェット1キロ粒剤 イノベーター散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	18	20	22	24	26	28	30
	株間	株/坪	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り
4 条 植	22	50	5.3	5.5	5.6	5.7	5.8	5.9	6.1	6.2
	18	60	5.2	5.3	5.4	5.5	5.6	5.7	5.8	5.9
	16	70	5.1	5.2	5.3	5.3	5.4	5.5	5.6	5.7
	14	80	5.0	5.1	5.2	5.2	5.3	5.4	5.5	5.5
	12	90	4.9	5.0	5.0	5.1	5.2	5.2	5.3	5.4
5 条 植	22	50	5.6	5.7	5.9	6.0	6.2	6.3	6.5	6.6
	18	60	5.4	5.5	5.6	5.7	5.9	6.0	6.1	6.2
	16	70	5.3	5.4	5.5	5.6	5.7	5.8	5.9	6.0
	14	80	5.2	5.2	5.3	5.4	5.5	5.6	5.7	5.8
	12	90	5.0	5.1	5.2	5.3	5.4	5.5	5.5	5.6
6 条 植	22	50	5.8	6.0	6.2	6.4	6.5	6.7	6.9	7.1
	18	60	5.6	5.7	6.0	6.2	6.3	6.3	6.4	6.6
	16	70	5.4	5.6	5.7	5.8	6.0	6.1	6.2	6.3
	14	80	5.3	5.4	5.5	5.6	5.8	5.9	6.0	6.1
	12	90	5.2	5.3	5.4	5.5	5.6	5.7	5.8	5.9
8 条 植	22	50	6.3	6.5	6.8	7.0	7.3	7.5	7.7	8.0
	18	60	6.0	6.2	6.3	6.5	6.7	6.9	7.1	7.3
	16	70	5.8	6.0	6.1	6.3	6.5	6.7	6.8	7.0
	14	80	5.6	5.8	5.9	6.1	6.2	6.4	6.5	6.7
	12	90	5.4	5.6	5.7	5.8	6.0	6.1	6.2	6.3
10 条 植	22	50	6.8	7.1	7.4	7.7	8.0	8.3	8.6	8.9
	18	60	6.3	6.6	6.8	7.1	7.3	7.6	7.8	8.1
	16	70	6.1	6.3	6.6	6.8	7.0	7.2	7.4	7.7
	14	80	5.9	6.1	6.3	6.5	6.7	6.9	7.1	7.2
	12	90	5.7	5.9	6.0	6.2	6.3	6.5	6.7	6.8

マーシェット1キロ粒剤 イノベーターⅡ 散布目安表

目安表の目盛りは最初に散布量を確認するための目安としてください。

横取り回数			16	18	20	22	24	26	28	30
	株間	株/坪	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り	目盛り
4 条 植	22	50	5.55	5.8	5.9	6.0	6.1	6.2	6.4	6.5
	18	60	5.45	5.6	5.7	5.8	5.9	6.0	6.1	6.2
	16	70	5.35	5.5	5.6	5.6	5.7	5.8	5.9	6.0
	14	80	5.25	5.4	5.5	5.5	5.6	5.7	5.8	5.8
	12	90	5.15	5.3	5.3	5.4	5.5	5.5	5.6	5.7
5 条 植	22	50	5.85	6.0	6.2	6.3	6.5	6.6	6.8	6.9
	18	60	5.65	5.8	5.9	6.0	6.2	6.3	6.4	6.5
	16	70	5.55	5.7	5.8	5.9	6.0	6.1	6.2	6.3
	14	80	5.45	5.5	5.6	5.7	5.8	5.9	6.0	6.1
	12	90	5.25	5.4	5.5	5.6	5.7	5.8	5.8	5.9
6 条 植	22	50	6.05	6.3	6.5	6.7	6.8	7.0	7.2	7.4
	18	60	5.85	6.0	6.3	6.5	6.6	6.6	6.7	6.9
	16	70	5.65	5.9	6.0	6.1	6.3	6.4	6.5	6.6
	14	80	5.55	5.7	5.8	5.9	6.1	6.2	6.3	6.4
	12	90	5.45	5.6	5.7	5.8	5.9	6.0	6.1	6.2
8 条 植	22	50	6.55	6.8	7.1	7.3	7.6	7.8	8.0	8.3
	18	60	6.25	6.5	6.6	6.8	7.0	7.2	7.4	7.6
	16	70	6.05	6.3	6.4	6.6	6.8	7.0	7.1	7.3
	14	80	5.85	6.1	6.2	6.4	6.5	6.7	6.8	7.0
	12	90	5.65	5.9	6.0	6.1	6.3	6.4	6.5	6.6
10 条 植	22	50	7.05	7.4	7.7	8.0	8.3	8.6	8.9	9.2
	18	60	6.55	6.9	7.1	7.4	7.6	7.9	8.1	8.4
	16	70	6.35	6.6	6.9	7.1	7.3	7.5	7.7	8.0
	14	80	6.15	6.4	6.6	6.8	7.0	7.2	7.4	7.5
	12	90	5.95	6.2	6.3	6.5	6.6	6.8	7.0	7.1